


Home of Victory



HeatoN - | - Select

keyboard1

User Manual

Welcome Home.

This is evolved gaming gear, co-developed, tested and approved by eSport legend HeatoN. Serious performance with a sophisticated style that fits a new home of victory, without compromise.

ZON – Home of Victory



APPROVED BY A LEGEND

ZON – Home of Victory is tournament-grade gaming gear that stands out for its performance and responsiveness under pressure. But don't take our word for it. Take the word of HeatoN who co-developed and approved each ZON product after immense amount of testing and tweaking every last detail. And it wasn't just about how everything felt, it was also about how everything looked.

HeatoN is a legend in the world of eSports. One of the very first professional gamers, he's always been a fearless pioneer, taking himself – and eSports – to new heights. With ZON, he saw the opportunity to be there from the start, helping bring a new standard in gaming gear design and performance to the world. And most importantly bringing it to people like himself – gamers who need to balance their passion for gaming with the realities of everyday life.

The clean, stylish looks of ZON gaming gear were everything he wanted for himself and his home life. But to get his seal of approval, HeatoN Select, it had to deliver tournament-grade performance. After 500 hours testing and optimizing each product, feeling every last sensation and response he was getting from his hands, eyes, heart and mind, HeatoN was finally satisfied. The result is a selection of gaming mice, mousepads, keyboards and headsets that he considers to be among the best he's ever used. And good enough to be HeatoN Select.

HeatoN – Select

"HeatoN"

ENGLISH

SVENSKA

NORSK

2

7

12

Specifications

Switches	Kailh Red
Key travel distance	4 mm
Quantity	105 keys
Size with palmrest	442 x 195 x 37 mm
Size without palmrest	442 x 137 x 37 mm
Weight	1080 g
Cable length	1.8 m
Lifetime	50 000 000 times

Interface

USB 2.0

System requirements

Windows XP /Vista/Win7/Win8/ Win10

(Internet connection for optional software download)

FN+F1 =Music

FN+F7=Play/Pause

FN+F2=Volume-

FN+F8=Stop

FN+F3=Volume+

FN+F9=Email

FN+F4=Mute

FN+F10=Homepage


FN+F5=Prev Track

FN+F11 =MyComputer

FN+F6=Next track

FN + F12=Backlit

modes selection




Key features

FN + ▲	=	Backlit brightness up
FN + "Scroll Lock"	=	Backlit color selection
FN + ◀	=	Backlit speed -
FN + <small>Prt Sc Sys Rq</small>	=	Backlit off
FN + ▼	=	Backlit brightness down
FN + ▶	=	Backlit speed+

For more key features, see www.zon.gg

Installing the keyboard



USB-Port



USB-Plug

Connect the USB-plug into USB port of your computer, the system will auto-install this device. Your device is ready to be used once installation is complete.

When this keyboard is plugged into the computer, all keycaps will light up with backlight.

Precautions

Incorrect use will damage the keyboard, so please pay attention to the following usage points:

1. Do not bump the keyboard.
2. Do not put the keyboard in liquid.

If the keyboard light is on after shutdown:
The motherboard's boot function is the most common cause of the keyboard still lighting up after shutdown.

Specifikationer

Switches	Kailh Red
Tangentens nedslagsträff	4 mm
Antal	105 Tangenter
Storlek med handledsstöd	442 x 195 x 37 mm
Storlek utan handledsstöd	442 x 137 x 37 mm
Vikt	1080 g
Kabellängd	1.8 m
Livslängd	50 000 000 Knapptryckningar

Gränssnitt

USB 2.0

Systemkrav

Windows XP /Vista/Win7/Win8/ Win10
(Internetanslutning för valfri nedladdning av programvara)

FN+F1=Musik

FN+F2 =Volym-

FN+F3=Volym+

FN+F4=Ljud av

FN+F5=Föregående spår

FN+F6= Nästa spår

FN+F7= Spela upp/

Pausa


FN+F8=Stoppa

FN+F9=E-post

FN+F10=Startsida

FN+F11=Min dator

FN + F12 =Val av
belysningsläge




Tangentfunktioner

FN + ▲	=	Öka belysningsstyrka
FN + "Scroll Lock"	=	Val av belysningsfärg
FN + ◀	=	Belysningshastighet -
FN + ^{Prt Sc} _{Sys Rq}	=	Belysning av
FN + ▼	=	Minska belysningsstyrka
FN + ▶	=	Belysningshastighet +

Fler tangentfunktioner finns på www.zon.gg

Installera tangentbordet



USB-Port



USB-Kontakt

Anslut USB-kontakten till USB-porten på datorn.
Operativsystemet på datorn installerar den här enheten automatiskt.

Du kan använda tangentbordet när installationen är slutförd.

När det här tangentbordet är anslutet till datorn lyser alla tangenter.

Säkerhetsföreskrifter

Felaktig användning skadar tangentbordet, så var uppmärksam på följande användningsföreskrifter:

1. Undvik att stöta till tangentbordet.
2. Sänk inte ned tangentbordet i vätska.

Om ljuset från tangentbordet är påslaget efter avstängning:

Moderkortets startfunktion är den vanligaste orsaken till att ljuset från tangentbordet fortfarande är påslaget efter avstängning.

SVENSKA

Spesifikasjoner

Switches	Kailh Red
Nøkkeltreff	4 mm
Antall	105 taster
Størrelse med håndleddstøtte	442 x 195 x 37 mm
Størrelse uten håndleddstøtte	442 x 137 x 37 mm
Vekt	1080 g
Ledningslengde	1.8 m
Levetid	50 000 000 Aktiveringer

Systemkrav

Windows XP /Vista/Win7/Win8/ Win10
(Internett-tilkobling for valgfri nedlasting av programvare)

FN+F1=Musikk

FN+F2=Volum-

FN+F3=Volum+

FN+F4=Lyd av

FN+F5=Forrige spor

FN+F6= Neste spor

FN+F7=Spill/pause


FN+F8=Stopp

FN+F9=E-post

FN+F10=Hjemmeside

FN+F11=Min datamaskin

FN+ F12=Valg av modus
for bakgrunnsbelysning



Tastefunksjoner

FN + ▲	=	Bakgrunnslysstyrke opp
FN + "Scroll Lock"	=	Bakgrunnslys fargevalg
FN + ◀	=	Bakgrunnslyshastighet -
FN + <small>Prt Sc Sys Rq</small>	=	Bakgrunnslys av
FN + ▼	=	Bakgrunnslysstyrke ned
FN + ▶	=	Bakgrunnslyshastighet+

For flere tastefunksjoner se www.zon.gg

Installere tastaturet



USB-Port



USB-Kabel

Stikk USB-kabelen inn i USB-porten på datamaskinen, og datamaskinens operativsystem vil automatisk installere denne enheten.
Du kan bruke tastaturet under installasjonen det er ferdig.

Når dette tastaturet er koblet til datamaskinen, vil alle tastaturhettene ha bakgrunnsbelysning.

Forsiktighetsregler

Feil bruk vil skade tastaturet, så ta hensyn til følgende punkter ved bruk:

1. Ikke rist tastaturet.
2. Ikke senk tastaturet ned i væske.

Hvis lyset på tastaturet er på etter at du har slått av:
Tastaturet får fortsatt strøm fra hovedkortet. Det
er den vanligste grunnen til at tastaturet fremdeles
lyser etter at du har slått av.

www.zon.gg

